(TOOL 1 - FlatMill:0.25 - DESC: 0.2500 DIA, 2 FLUTE, CARBIDE MAT) MAT) **G-Code Editor** AT) Reference Guide RhinoCAM 2025 Published: February 2025 N5 (Work Zero) N6 G54 N7 (2 1/2 Axis Profiling (Outer)) N8 (Tool Diameter = 0.25 Length = 2.0) N9 G20 T1 M6 N10 S10000 M3 N11 G90G0X-1.2533Y-0.3524 N12 G43Z0.25H1 N13 M8 N14 G0 N15 G1Z-0.25 F97.5 N16 G41 G1 X-1.2533 Y-0.3524 D1 F146.25 N17 G1X-1.1678Y-0.1175 N18 G1X-1.125YO. N19 G1Y1, F195. **MecSoft Corpotation** N20 G1Y1.25 © Copyright 1998-2025 N21 G17 N22 G03X-1.25Y1.125I-0.125J0. N23 G1X-1. N24 G1X1. N25 G1X1.25

N2 G40 G49 G80

( BEGIN TOOL LIST )

N26 G03X1.125Y1.25I0.J0.125

N27 G1Y1. N28 G1Y-1.

N3 ( STOCK SIZE: X2.125 Y2.125 Z0.25 )

# **Table of Contents**

Welcom	ıe			5
	1 Ove	rview		5
	2 Feat	ures		6
	3 Unde	erstanding.		7
		•		
,	4 1101	K 1 10W		
Quick S	tart			9
CAM Re	sour	ce Guid	е	11
User Int	erfac	e		12
	1 Pref	erences		12
	ı	User Interfac		13
		•		
		•		
			r	
		-		
		•		
	;	Simulate Tab		35
	(	Online Help		37
<b>Project</b>	Tab			39
	1 Mac	hine MCS S	etup	41
	2 Setu	p Pane		45
	;	Stock		45
		Box Stock		46
			Stock	
		-	tock	
		•	der Stock	
			r Selection	
	-		T Gelection.	
		-		
	3 G-C	de Pane		64
	ı	Load		64
	-			
,	4 File	Operations	Pane	67
	ı	Merge Files		67
		•		

	Save	81				
	Output	83				
5	Right-Click Menu	84				
	Edit-G-Code-File	84				
		9 85				
	Delete G-Code File					
Edit Tab		90				
1	Add Line Numbers					
2	Insert Spaces95					
3	Make Upper Case					
4	Delete Line Numbers					
5	Delete Spaces					
6	Make Lower Case					
7	Cut Text	101				
8	Copy Text	103				
9	Paste Text	104				
10	Find Text	106				
11	Find & Replace Text.	107				
12	Undo Last Edit	109				
13	Print G-Code	111				
14	Save G-Code	112				
15	Save As	113				
16	Show G-Code Info	114				
17	Select Full Line	116				
18	Right-Click Menu	117				
	Go to Bottom					
	•					
		119				
	•					
		123				
		125				
	Undo Last Edit					
Simulate	Tab	130				
1	Simulate Options					
	Simulation Preferen	ces				
	Simulation Speed					
2						
	Play Simulation					

	Step Thru Simulation	136
	Display Simulation Levels	137
	Simulate to End	138
	Pause Simulation	139
	Stop Simulation	140
Functio	ons from the MILL Module	142
Find Mo	144	
	Index	151

## Welcome



# **G-CODE Editor Module 2025**

#### Prefer Printed Documentation? Check Here!

Welcome to the RhinoCAM-G-Code Editor Online Help! This help system contains helpful information about every command and feature of the RhinoCAM-G-Code Editor. G-CODE Editor can assist you with editing g-code files created with RhinoCAM or from other sources. It can also be used to navigate and perform cut material simulations of g-code files. Select a topic from the Contents, Index or Search tabs located on the left. You can also select a Related Topic from below to get started. The Features topic contains links to every command in the RhinoCAM-G-Code Editor!

For additional assistance and resources we invite you to visit the <u>Find More Resources</u> topic. We hope you enjoy the RhinoCAM-G-Code Editor!



**Overview** 

**Features** 

**Understanding** 

**Work Flow** 

#### 1.1 Overview

G-CODE Editor is a companion module that runs inside of RhinoCAMRhinoceros. G-CODE Editor assists users with editing g-code files created with RhinoCAM or from other sources. It can be used to navigate and perform cut material simulations of g-code files.



RhinoCAM-G-Code Editor

**Features** 

**Understanding** 

**Work Flow** 

## 1.2 Features

The following features are included in the RhinoCAM-G-Code Editor module.

- Project
  - Machine MCS Setup
  - <u>Preferences</u>
  - Stock
  - <u>Tool Library</u>
  - Tool Stations
  - Load G-Code File
  - Project Information

- Merge Files
- Transform Project
- Z Instance Project
- XY Instance Project
- Save Project
- Output Project
- Editing (Right-Click Menu)
  - Cut/Copy/Paste
  - Undo Last Command
  - Print G-Code File
  - Save File
  - Go to Bottom

- Go to Top
- Go to next Tool
- Go to next Spindle
- Go to next Feedrate
- Find & Replace Text
- Editing (Ribbon Bar Menu)
  - Add Line Numbers
  - Delete Line Numbers
  - Insert Delimiter Spaces
  - Delete Delimiter Spaces
- Make all Upper Case
- Make all Lower Case
- G-Code Information
- Find & Replace Text

- Simulation
  - Simulation Preferences
  - Simulation Speed
  - <u>Simulation Mode</u>
  - Play Simulation

- Display Simulation in Levels
- Simulate to End
- Pause Simulation
- Stop Simulation

Related Topics

Welcome

Overview

**Understanding** 

**Work Flow** 

## 1.3 Understanding

The RhinoCAM-G-Code Editor module can edit g-code files that you create with RhinoCAM. It can also be used to edit g-code files generated from other systems that produce ISO standard g-code files. You can also define tool libraries, tool cribs and perform cut material simulations.

Related Topics

RhinoCAM-G-Code Editor

Overview

**Features** 

**Work Flow** 

#### 1.4 Work Flow

The following is a basic procedural work flow for using the RhinoCAM G-CODE Editor module:

Step 1: Load a G-Code Files

Run the RhinoCAM G-CODE Editor module and Load the g-code file or files using the commands on the Project tab. Your g-code files will be listed in the Project tree.

Step 2: Edit G-Code Files

Edit the G-Code file using the Edit tab functions. You can perform many automatic and manual editing tasks, save and print your G-Code files.

Step 3: Tool Motion Simulations (Optional)

To perform tool motion simulations, simply place the cursor at the top of the G-Code file and press the down arrow key and the tool motion will display on the graphics screen.

Step 4: Cut Material Simulations (Optional)

To perform a cut material simulations, load a Tool Library generated from RhinoCAM, setup your Tool Crib with the tool numbers used in your g-code files. Then return to the Project tab, right-click on the G-Code file and select Simulate.

Step 5: Save your G-Code Files

When you are done editing your g-code you can Save the g-code files or Output them directly to another program, of your choice such as a DNC program to communicate them directly to your CNC machine. See <a href="Preferences">Preferences</a> > <a href="Text Editor">Text Editor</a> to define your output program.

Related Topics

**Welcome** 

**Overview** 

**Features** 

**Understanding** 

#### **Quick Start**

Quick Start Guides for each RhinoCAM module are available in both PDF and Video format. Refer to the following information to access these guides:

What's New!

What's New in RhinoCAM 2025

The Complete Quick Start Video Play List

Here is a link to the complete 2025 Video Play List

How to Access the Quick Start Guide Documents


To help you quickly get started in working with each module, select one of the Help buttons located on the RhinoCAM Learning Resources dialog.

You will find:

- Quick Start Guides
- What's New documents
- Online Help links


The Quick Start Guides will help you step through an example tutorial which will illustrate how to use the module. To access the Learning Resources dialog:

1. From the Rhino Main Menu, drop down the Main menu and select Learn ...



To access the Learning Resources dilog in RhinoCAM

- 2. Select a document from the Learning Resources dialog to get started using the module of your choice.
  - You can also select the Open Quick Start Files Folder button located at the bottom of the dialog to open the Quick Start folder where the source files (start and completed versions) are located.



**Learning Resources Dialog** 


Related Topics

**Find More Resources** 

## **CAM Resource Guide**

Download this PDF Guide for a list of the available RhinoCAM Resources.

2025 RhinoCAM Resource Guide



## The 2025 RhinoCAM Resource Guide!

18 Pages


Lists PDF downloads and Online resources including Quick Start Guides, Reference Guides, Exercise Guides, Tutorials and More.

Prefer Printed Documentation? Check Here!

## **User Interface**

RhinoCAM-G-CODE Editor adheres to the Windows standard for user interface design and is seamlessly integrated into the Rhinoceros SolidWorksAlibre Designscreen layout. A screen image of RhinoCAM-G-CODE Editor running inside of RhinocerosSolidWorksAlibre Design is shown below:

## The User Interface



Related Topics

**Preferences** 

**G-Code Browser** 

**Project Tab** 

**Edit Tab** 

Simulate Tab


#### 4.1 Preferences

You can set various System Preferences that will be saved even after you exit the program. Select the Preferences icon from the G-Code Browser. When you install a new RhinoCAM update you can choose to import your Preferences from one version to the next.

To Access this Command:



## The Preferences Icon



Set System Preferences menu item

## Related Topics

**User Interface** 

**System Preferences** 

**Text Editor Preferences** 

**Toolpath Preferences** 

**Stock Preferences** 


**Cutting Tools Preferences** 

**Simulation Preferences** 

#### 4.1.1 User Interface

Here you can set preferences related to the g-code text editor including colors and associated programs and folders. You can use the Reset to defaults button if you want to revert to the default factory install settings.

- To Access this Command:
  - click: Super Interface
- Preferences > Text Editor



Preferences > User Interface

## Language Language


#### **System language**

Use this to set the system language of the plugin's User Interface.

# Tool Tips Preferences


#### **Show Context Tool Tips**

Check this box to display Context ToolTips when the mouse moves over a parameter in a dialog. A definition of the parameter will pop-up automatically. **Note** that Context ToolTips may not be available for ALL dialogs. You can also set the ToolTip Delay in seconds. This is the amount of time it takes to display the Context ToolTip when the mouse activate it.



#### **Show Expression Results in Tool Tips**

You can enter expressions in any dialog field that expects a numerical value and the value will be computed and entered automatically. Check this box to pop-up the results of any expressions in a ToolTip balloon. An example is shown below.




**Show Expressions in ToolTip** 

#### **Tool Tip Delay**

When Show context ToolTips is checked, this value defines the Delay in seconds it takes for a ToolTip to display once the cursor moves over it.

# Ribbon Style

This allows the selection of different themes that change how the Browser windows appear. The borders, colors, highlighting, and shadowing of standard buttons, dialogs, and windows are controlled by which theme is selected.



Example Ribbon Style: Office 2010 Silver

# Additional Open File Extensions

If your g-code files have an extension other than \*.nc you can add that extension here. Enter the extension in the field provided and then pick the Add button.



#### Save Preferences

#### **Save Current Preferences to Registry**

If you have your preferences set the way you want them and do not want them top change, select this button to save the current preferences to your Windows registry. Doing this will force them to be loaded when you create new files.

# Related Topics

**Text Editor Preferences** 

**Toolpath Preferences** 

**Stock Preferences** 

**Cutting Tools Preferences** 

**Simulation Preferences** 


#### 4.1.2 Text Editor

Here you can set preferences related to the g-code text editor including colors and associated programs and folders. You can use the Reset to defaults button if you want to revert to the default factory install settings.

# To Access this Command:

click: > Text Editor

## Preferences > Text Editor



Preferences > Text Editor

Text Editor Colors

You can specify the default colors to display for Rapid, Linear and Arc moves as well as for Line Numbers and Comments within the G-Code Editor. Use the color selector available for each.

```
1 %
2 G40 G49 G80 G98
  ;Setup 1
  ;2 1/2 Axis Profiling (Outer) 	← Comments
  G20 G90
  S10000 M03

    Rapid Moves

  G00 Z0.5 ←
  X-0.8976 Y-1.2533
10 G01 Z0. F97.5

    Linear Moves

11 X-1.1325 Y-1.1678 F146.25 ←
12 X-1.25 Y-1.125
13 G17
14 G03 X-1.125 Y-1.25 IO. J-0.125 F195. ← Arc Moves
15 G01 Y-1.
16 YO.
                     Text Editor Color Preferences
```

You can specify the default save directory. Pick the button to select a different folder. When you pick <u>Save</u> from the <u>Project</u> tab, this is the folder where the file is saved. To overwrite the original g-code, use the <u>Save G-Code</u> command from the <u>Edit</u> tab.

# Related Topics

Save Directory

**User Interface Preferences** 

**Toolpath Preferences** 

**Stock Preferences** 


**Cutting Tools Preferences** 

**Simulation Preferences** 

#### 4.1.3 Toolpath

Here you can set Toolpath related preferences including colors, display, format and feedrate. You can use the Reset to defaults button if you want to revert to the default factory install settings.


# To Access this Command: click: Toolpath Preferences > Toolpath



Preferences > Toolpath

## Toolpath Colors


You can specify the default colors to graphically display Rapid, Linear and Arc moves. Use the color selector available for each.



**Toolpath Display Color Preferences** 

## Toolpath Display

Here you can set the line thickness for the display of all toolpaths.



# Circle Center (I,J,K)

I,J,K refers to the center point location for arc motions. In this section you can define how arc motions are formatted in the output G-Code file. Select from the following options:

- Absolute
- Vector from Center to Start
- Vector from Start to Center
- Unsigned Vector from Start to Center

# Feedrate Speed

Here you can specify feedrate values for the G-Code file. Select from the following:

- Rapid Feed
- Nominal Cut Feed

## Related Topics

**User Interface Preferences** 

**Text Editor Preferences** 

**Stock Preferences** 

**Cutting Tools Preferences** 

**Simulation Preferences** 


#### 4.1.4 Stock

Here you can set Toolpath related preferences including colors, display, format and feedrate. You can use the Reset to defaults button if you want to revert to the default factory install settings.

To Access this Command:



## Preferences > Stock



Preferences > Toolpath

## Stock Colors

Here you can set the default colors for Stock and Cut Stock. Use the color selector available for each.

# Stock Model Display Transparency

Use the slider to set the transparency of the Stock Model Display.

# Related Topics

**User Interface Preferences** 

**Text Editor Preferences** 

**Toolpath Preferences** 

**Cutting Tools Preferences** 

**Simulation Preferences** 


#### 4.1.5 Cutting Tools

Here you can set Cutting Tool related preferences. You can use the Reset to defaults button if you want to revert to the default factory install settings.

To Access this Command:



## Preferences > Cutting Tools



Preferences > Cutting Tools

# Cutting Tool Color

Here you can set the default color for the Cutting Tool during simulations. Use the color selector available for each.

# Related Topics

**User Interface Preferences** 

**Text Editor Preferences** 

**Toolpath Preferences** 

**Stock Preferences** 


**Simulation Preferences** 

#### 4.1.6 Simulation

Here you can set Simulation related preferences. You can use the Reset to defaults button if you want to revert to the default factory install settings.

To Access this Command:

Preferences > Simulation



Preferences > Simulation

## Simulation Mode

There are two simulation modes.

#### • Simulate by Moves

One pick of the Step icon on the <u>Simulate tab</u> moves the Cutting Tool one complete move (i.,e., start to end). See <u>Maximum Display Interval below</u>. This option is the same as checking the <u>Simulate By Moves</u> box on the <u>Simulate tab</u>.

#### Simulate by Distance

One pick of the Step icon on the <u>Simulate tab</u> moves the Cutting Tool a specified distance. See <u>Maximum Display Interval below</u>. This option is the same as unchecking the <u>Simulate By Moves box on the Simulate tab</u>.

#### • Maximum Display Interval

You can control the speed of the simulation using the slider bar and the Maximum Display Interval. When using Simulate by distance mode, the speed is determined as # of Motions / Distance.

## Simulation Accuracy

Use this slider to adjust the simulation display accuracy.

#### Simulation Tolerance

The Simulation Accuracy slider provides a high-level of adjustment and the Simulation Tolerance provides a more granular level of control. Note that the Simulation Tolerance will have a direct affect on simulation time.



#### **Disable Advanced OpenGL**

Check this box only if you have an older graphics card adapter that does not support advanced OpenGL (i.e., OpenGL 2). Some older cards may only support OpenGL 1 for example. If you experience graphics instability checking this box may help resolve the issue.

Related Topics

**User Interface Preferences** 

**Text Editor Preferences** 

**Toolpath Preferences** 

**Stock Preferences** 


**Cutting Tools Preferences** 

#### 4.2 G-Code Browser

The G-Code Browser has four main modes of operation represented by tabs at the top of the browser window. These are Project, Edit, G-Code Edit and Simulate. Each tabbed view also incorporates a ribbon toolbar of commands at the top. These toolbars group associated commands into panes.

Each menu tab is shown below:


The Project Tab



G-Code Browser, Project Tab


# The Edit Tab





# The Simulate Tab





G-Code Browser, Simulate Tab

## Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Simulate Tab


## 4.2.1 Project Tab

The Project tab is Selecting the Program tab in the Mops Browser shows 3 groups of menus that provide access for specifying Machine, Stock and defining Machining Operations.

#### To Access this Command:



The Project Tab



Ribbon Bar Options

Project Contains Project related commands.

- Use these icons to maximize and minimize the ribbon bar menus.
  - Display the <u>Preferences</u> dialog.
  - Display the Online Help system.


## Project Setup Pane

Stock Displays a menu of Stock definition commands.


Library Displays the Tool Library dialog.

Numbers Displays the Tool Crib dialog.


## Project G-Code Pane



## Project File Operations Pane



## Project Tab, Right-Click Menu



## Related Topics

**Project Tree** 

**Edit Tab** 

Simulate Tab

Online Help

## 4.2.2 Project Tree

Project The Project tree is located under the Project tab. It contains all of the elements needed for a specific project, including stock model, tool library, tool crib and g-


code files. The Project tree can also alert you to issues that need to be addressed by flagging items for attention.

#### To Access this Command:

click: Project


# The Project Tab

You must have the Project tab selected in order to see the Project tree.



## Returning to the Project Tab


You can return to the Project tab by selecting this icon located on the top G-Code Browser when either the Edit, G-Code Edit or Simulate tabs are active.



G-Code Browser, Return to Project Tab menu item

# How Stock is Defined in the Project Tree


If there no stock yet defined, the Stock icon in the Project tree will say "Stock - None". Once a stock is defined, the Stock icon in the Project tree will indicate the type of stock that is defined. Refer to the two Project tree images. The image on the left has no Stock yet defined. The image on the right has Box Stock defined.



## Red Flags in the Project Tree


If items are flagged in the Project tree it means that they need your attention.

For example if a g-code file has been modified but has not yet been saved or output, it will be flagged as shown in the example below.



When a g-code file is flagged

If you load a g-code file that uses a tool number that is currently undefined in your tool crib, it will be flagged as shown below.



When a tool is flagged

## Related Topics

**Project Tab** 


**Edit Tab** 


Simulate Tab

Online Help

#### 4.2.3 Edit Tab

When you double-left-click on a G-Code file from the Project tree, that file is loaded into the G-Code Editor. The Edit tab contains commands to Modify and Navigate the g-code file. The Edit tab and commands are listed below.





## Ribbon Bar Options

Edit Contains file Edit related commands.

Returns to the Project tab.


Minimizes and maximizes the ribbon bar menu.

Displays the <u>Preferences</u> dialog.

Displays the Online Help system.

#### Edit Tab

Add line #s Add line numbers to the g-code file.





## Edit Tab, Display Toolbar



- Stock Model Visibility: Turn on/off stock model
- Part Model Visibility: Turn on/off part model display during simulation.
- Toolpath Visibility: Turn on/off toolpath display
- Follow Toolpath Display: The toolpath is displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath after the tool passes.
- Trace Toolpath Display: The toolpath is not displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath before the tool passes.

P

Segment Toolpath Display: The toolpath is only displayed for the segment that the tool is currently on.

Related Topics

**Project Tab** 

**Project Tree** 

Simulate Tab

Online Help


#### 4.2.4 Simulate Tab

When you double-left-click on a G-Code file from the Project tree, that file is loaded into the G-Code Editor. The Simulate tab contains commands to perform tool motions and cut material simulations of the g-code file. The Simulate tab and commands are listed below. **Note**: You must have <u>Stock</u>, <u>Tool Library</u> and <u>Tool Crib</u> defined before performing a Simulation.


#### To Access this Command:


```
Simulate
```

#### Simulate tab




G-Code Browser, Simulate Tab









- Toolpath Visibility: Turn on/off toolpath display
- Follow Toolpath Display: The toolpath is displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath after the tool passes.
- Trace Toolpath Display: The toolpath is not displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath before the tool passes.
- Segment Toolpath Display: The toolpath is only displayed for the segment that the tool is currently on.

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Online Help


### 4.2.5 Online Help

You can access this online help system from the G-Code Browser.


# To Access this Command:

click:

## The Online Help Icon



Online Help menu item



RhinoCAM-G-Code Editor Online Help System

# Related Topics

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Simulate Tab


# **Project Tab**

The Project tab is Selecting the Program tab in the Mops Browser shows 3 groups of menus that provide access for specifying Machine, Stock and defining Machining Operations.


## To Access this Command:



## The Project Tab




# Ribbon Bar Options




Display the **Preferences** dialog.



## Project Setup Pane





Numbers Displays the Tool Crib dialog.

## Project G-Code Pane

Load a g-code file into the Project tree.

Display <u>Information</u> about the g-code files currently loaded into the Project.

## Project File Operations Pane

Merge Files Merge two selected g-code files into one file.

Transform Displays the Transform g-code dialog.

**Z** Instance Displays the **Z** Instance g-code dialog.

**EXY Instance** Displays the <u>XY Instance</u> g-code dialog.

Save Saves all g-code files currently loaded into the Project.

Output Outputs the g-code files currently loaded into the Project.

# Project Tab, Right-Click Menu

Edit the selected G-Code file.

Simulate Simulate Selected G-Code file.

Info Display information about the selected G-Code file.

Delete the selected G-Code file.

**Project Tree** 

**Edit Tab** 

Simulate Tab


Online Help

## 5.1 Machine MCS Setup




You can set the cutting direction and alignment using the Machine Coordinate System (MCS) dialog. This orients the coordinates defined in the any g-code files that are currently loaded into the editor.

### To Access this Command:




# G-Code Browser: Project tab, Stock menu



**Edit the Machine MCS** 

Dialog Box: Machine



Dialog Box: Machine (MCS) Setup

# The Machine Coordinate System (MCS)

The Machine Coordinate System (MCS) is displayed as a triad with **Blue** line representing the Z-axis, **Red** representing X-axis and **Green** representing the Y-axis. The WCS is displayed the same way as MCS and is located at the origin. The lengths of the WCS arrows are shorter when compared to MCS.






# Align to

This aligns the MCS orientation. Select from the following:

#### **Machine Tool Coordinate System**


Aligns the Setup Coordinate System to Machine Tool Coordinate System.



Align To: World Coordinate System

#### **Active View Construction Plane**


Setting the MCS to the orientation of the active viewport of the construction Plane.



Align To: Active Construction Plane

#### **Geometry: Part Surface**


User can select a point on a surface determine the alignment of MCS.



Align To: Geometery, Part Surface

#### **Geometry: Planar Curve**

User can select a planar curve (2D sketch) to determine the alignment of MCS.



Align To: Geometry, Planar Curve

# Set Orientation Parallel to

Allows you to set the Machine Coordinate System parallel to the World X Y or Z co-ordinate axis.

World X orients the Z axis of MCS parallel to World X axis.

World Y orients the Z axis of MCS parallel to World Y axis.

World Z orients the Z axis of MCS parallel to World Z axis.


Orientatio n Parallel to	Triad Display		
	MCS Visibility ON	WCS Visibility ON	MCS Visibility ON
	WCSVisibility OFF	MCS Visibility OFF	WCS Visibility ON
World X	K	K	<
World Y	~	K	*
World Z	K	K	

Rotate about

Allows you to rotate the Machine Coordinate System in X Y Z coordinate axis by any angle specified under Spin Angle. Specify Spin Angle and click the axis to rotate about. Clicking the same coordinate axis button multiple times rotates by the specified angle incrementally. For example if you set the Spin Angle = 90 and click X Axis button 2 times, the MCS is rotated about X coordinate axis by 180 degrees.

# Coordinate System Origin

This translates the MCS origin to the desired location. This can be set to any location on the part geometry.



Use Coordinate System Origin to translate the MCS origin to the desired location

## Reset to Original

Resets MCS orientation to current MCS orientation.

# Related Topics

**G-Code Browser** 

**Project Tab** 

**Project Tree** 

# 5.2 Setup Pane


#### 5.2.1 Stock

This menu contains commands to create different types of Stock material in preparation for cut material Simulations. If there is no stock defined, Simulations will only show tool motions and not a cut material simulation.

### To Access this Command:



### G-Code Browser: Project tab, Stock menu



The Stock Menu

### Related Topics

Stock Menu

**Create Box Stock** 

**Create Part Box Stock** 

**Create Cylinder Stock** 

**Create Part Cylinder Stock** 

**Stock from Selection** 

**Delete Stock** 


#### 5.2.1.1 Box Stock

You can define the raw stock model as a simple box by selecting the Box Stock option from the <a href="Stock">Stock</a> menu on the <a href="Project">Project</a> tab of the <a href="G-Code Browser">G-Code Browser</a> and entering the Stock dimensions.






Box Stock menu item



G-Code Browser: Box Stock menu item

# Dialog Box: Box Stock

You can define the box by simply typing in the Length, Width and Height of the box in the corresponding edit boxes of the dialog. The corner position (origin) of the box can also be repositioned by picking the desired coordinate or by specifying the coordinate values in the corresponding edit boxes in the dialog (Xc, Yc, Zc). When you click on the OK button, a stock model based on your definition will be created and displayed.



Dialog Box: Box Stock


# Copy Model Bounding Box


When Copy Model Bounding Box is selected, the system calculates the bounding box of the part model as the XYZ extents of geometry of the part model and displays the XYZ Coordinate values under dimensions.

## Ignore Wireframe Geometry in Bounds Computation

Check this box to ignores all 2D and 3D curve geometries present in the part from stock bounding box computation.

Make sure to click Copy Model Bounding Box after you check or uncheck Ignore Wireframe Geometry in Bounds Computation.





Ignore Wireframe geometry - checked

Ignore Wireframe geometry – un-checked

Stock Menu

**Create Part Box Stock** 

**Create Cylinder Stock** 

**Create Part Cylinder Stock** 

**Stock from Selection** 

**Delete Stock** 


#### 5.2.1.2 Part Box Stock

You can define the raw stock model as a bounding box of the XYZ extents of geometry of the part model. You can then define offsets in any of the three coordinate directions to apply to the computed bounding box.

# To Access this Command:

click: Project > Stock > Part Box Stock ...


Part Box Stock menu item



G-Code Browser: Part Box Stock menu item

## Dialog Box: Part Box Stock


The system calculates the bounding box of the part model as the XYZ extents of geometry of the part model. You can then define offsets in any of the three coordinate directions to apply to the computed bounding box. The system will expand the bounding box by the offset amount in each of the coordinate directions. When you click on the OK button, a stock model based on your definition will be created and displayed.




Dialog Box: Part Box Stock

## Ignore Wireframe Geometry in Bounds Computation

Check this to ignore all 2D and 3D curve geometries present in the part from stock bounding box computation.



Ignore Wireframe geometry - checked



Ignore Wireframe geometry - un-checked

# Related Topics

**Stock Menu** 

**Create Box Stock** 

**Create Cylinder Stock** 

**Create Part Cylinder Stock** 

**Stock from Selection** 

**Delete Stock** 


#### 5.2.1.3 Cylinder Stock

You can define the raw stock model as a simple cylinder by selecting this option.

When creating a cylinder stock, the axis of the cylinder is automatically set to the World Z Axis unless you select a different axis from the dialog.



Cylinder Stock menu item




G-Code Browser: CylinderStock menu item

## Dialog Box: Cylinder Stock

You can define the cylinder by simply selecting the axis of the cylinder (either X Y or Z), specifying the center coordinates by typing in the values or graphically picking the center and then by specifying the radius and the length of the cylinder.

The Center (origin) of the stock can also be repositioned by specifying the coordinate values in the corresponding edit boxes in the dialog (Xc, Yc, Zc). When you click on the OK button, a stock model based on your definition will be created and displayed. You can switch to the Simulate tab of the browser window to display the stock model that was created.



Dialog Box: Cylinder Stock


## Copy Model Bounding Cylinder


User can also select Copy Model Bounding Cylinder to determine the smaller possible stock model that fit the part geometry.


## Ignore Wireframe Geometry in Bounds Computation

Check this ignore all 2D and 3D curve geometries present in the part from stock bounding cylinder computation.

Make sure to click Copy Model Bounding Cylinder after you check or uncheck Ignore Wireframe Geometry in Bounds Computation.







Ignore Wireframe geometry - un-checked

Stock Menu

**Create Box Stock** 

**Create Part Box Stock** 

**Create Part Cylinder Stock** 

Stock from Selection

**Delete Stock** 


#### 5.2.1.4 Part Cylinder Stock

You can define the raw stock model as a bounding cylinder of the XYZ extents of geometry of the part model. You can then define offsets to apply to the computed bounding box.



Stock → Part Cylinder Stock ...

Part Cylinder Stock menu item




G-Code Browser: Part CylinderStock menu item

## Dialog Box: Part Cylinder Stock

You can define the cylinder by simply selecting the axis of the cylinder (either X, Y or Z) and defining the radial and the axial offset distances. The bounding cylinder will be calculated and these offset values will be used to expand the cylinder in both the radial and axial direction.

Additionally you can specify the axial offset to be applied in both the positive and negative directions or only in the positive or only in the negative axial directions.





Dialog Box: Part Cylinder Stock


# Ignore Wireframe Geometry in Bounds Computation

Check this to ignore all 2D and 3D curve geometries present in the part from stock bounding cylinder computation.

When you click on the OK button, a stock model based on the part geometry and your definition will be created. You can switch to the Stimulate tab of the browser window to display the stock model that was created.







Ignore Wireframe geometry – un-checked

Stock Menu

**Create Box Stock** 

**Create Part Box Stock** 

**Create Cylinder Stock** 

**Stock from Selection** 

**Delete Stock** 

#### 5.2.1.5 Delete Stock




Use this command to Delete the currently defined Stock model. If there is no stock defined, Simulations will only show tool motions and not a cut material simulation.

# To Access this Command:



Delete Stock menu item



G-Code Browser: Delete Stock menu item

Stock Menu

**Create Box Stock** 

**Create Part Box Stock** 

**Create Cylinder Stock** 

**Create Part Cylinder Stock** 

Stock from Selection

#### 5.2.1.6 Stock from Selection

You can define the raw stock model from the currently active selected 3-D geometry.
You can select 3D surfaces and/or meshes and then selects Stock from Selection
option from Create Stock Model under the Program tab in Machining Browser.


No dialog will be invoked but the system will use the selected geometry and create a triangulated stock model. You can switch to the Stock tab of the browser window to display the stock model that was created.

Stock from Selection will fail to create stock if the selected 3D geometry is not a watertight model.

# To Access this Command:




Stock from Selection menu item



G-Code Browser: Stock from Selection menu item

# Stock from Selection Example

You can switch to the Simulate tab of the browser window to display the stock model that was created.



# Related Topics

Stock Menu

**Create Box Stock** 

**Create Part Box Stock** 

**Create Cylinder Stock** 

**Create Part Cylinder Stock** 

**Delete Stock** 


#### 5.2.2 Tool Library

Use this command to load a pre-defined Tool Library file (\*.csv). You can save a Tool Library (\*.csv) file from the MILL module Save Tool Library command. When you create your Tool Crib, the tools are selected from this Tool Library.

### To Access this Command:




## Tool Library menu item



G-Code Browser: Tool Library menu item


## Procedure

- 1. Select Library from the Project tab of the G-Code Browser and pick Load.
- 2. The File Open dialog will display. Navigate to the Tool Library file and pick Open to load it. The file extension must be \*.csv. You can save a Tool Library (\*.csv) file from the MILL module Save Tool Library command.
- 3. The Tool Library is loaded.



A Tool Library is loaded

4. Selecting a tool type icon from the menu at the top will display those tool types.



**Listing only Drill Tools** 

5. The default Tool Library (\*.csv) files saved from the MILL module contains the following data fields as shown in each column of the dialog. You can edit \*.csv files using an Excel compatible spreadsheet program.


Default Tool Data Fields Supported by the MILL Module are:

- Name
- Tool Type
- Diameter
- Corner Radius
- Taper
- Flute Length
- Tool Length

- Tool Number
- Tool Material
- Spindle RPM
- Cut Feed
- Adjust Register
- Cutcom Register
- Comments

# Tool Library Toolbar

Select an icon from the toolbar to display only those tools.



**User Interface** 

**Project Tab** 

Stock Menu

**Tool Crib** 


#### 5.2.3 Tool Crib

Use this command to create a Tool Crib for the current Project. This will assign a tool station number to each tool you load into the Tool Crib. Be sure to assign the same Tools and Tool Numbers that are used in your g-code files.

To Access this Command:




Tool Crib menu item



G-Code Browser: Tool Crib menu item


### Procedure

- 1. Select Numbers from the Project tab of the G-Code Browser.
- The Tool Crib dialog will display.
   Select the Add Station button to grab a tool from the default Tool Library.



The Tool Crib dialog, Add Station button

3. The Tool Crib dialog will minimize and the Tool Library dialog will display. Select a tool from the library and then pick OK. The selected tool will be assigned as tool station #1 (i.e., Tool #1).



Select a Tool from the Library and pick OK.

 You can use the icons on the right side of each Tool Station # to delete that station or reassign a tool to that station.
 Pick OK to accept the Tool Crib.

## Related Topics

**User Interface** 

**Project Tab** 

Stock Menu


**Tool Library** 

#### 5.3 G-Code Pane

#### 5.3.1 Load

Use this command to Load a g-code file into the G-Code Browser. You can load as many g-code files as you wish and work with them from the Project tab of the G-Code Browser. The example below shows three files loaded.

# To Access this Command:




Then use the File Browser to select a G-Code file to load.

The following G-Code file type extensions are supported:



Load menu item



G-Code Browser: Load g-code file menu item

**User Interface** 

**Project Tab** 

**Stock Menu** 


**Tool Library** 


**Tool Crib** 

Info

#### 5.3.2 Info


Use this command to get Information about all of the g-code files that are currently loaded into the Project of the G-Code Browser. Information includes file Name, Tool #, # of GoTo motions, Estimated Machining Time and file Size.





G-Code Browser: Info menu item

# G-Code Files Information Dialog



Files Information Dialog

Related Topics

**User Interface** 

**Project Tab** 

Stock Menu

**Tool Library** 

Tool Crib

## 5.4 File Operations Pane

Load


### 5.4.1 Merge Files

Werge Files
Use this command to merge g-code files that are currently loaded into the Project tab of the G-Code Browser. Merged files can be output as one g-code file using the Output command.

### To Access this Command:




### Merge Files menu item



G-Code Browser: Merge Files menu item


## Procedure

1. From the Project tab of the G-Code Browser, press and hold the <Ctrl> key while left-click selecting the g-code files that you want to merge.




G-Code Browser: Merge Files menu item

2. With the g-code files highlighted and selected, pick the Merge Files command from the Project tab.




G-Code Browser: Merge Files menu item

3. In the example above we have selected three g-code files to merge. The second and third files are merged into the first selected file that appears in the Project.




The second and third files are merged into the first selected file that appears in the Project.

- 4. Because the first g-code file has now changed, it is flagged (at the red arrow in the image above) to let you know that it has not yet been saved.
- 5. A double-left-click on the g-code file will load it into the G-Code Editor for viewing.



The merged file is loaded into the G-Code Editor

6. When done editing the g-code file, select the Back to Project icon to return to the Project tab.



Back to Project menu item

7. When satisfied, select the Output icon to save the new edited g-code file.

```
PPG-Decoded-haas-blog2_2 1_2 Axis Profiling (Outer) ...
                                               X
File Edit Format View Help
%
01234
G40 G49 G80
( STOCK SIZE: X2.125 Y2.125 Z0.25 )
( BEGIN TOOL LIST )
( TOOL 1 - FlatMill:0.25 - DESC: 0.2500 DIA, 2 FL
( ENDOF TOOL LIST )
(2 1/2 Axis Profiling (Outer))
( Tool Diameter = 0.25 Length = 2.0 )
G20 T1 M6
S10000 M3
G90G0X-1.2533Y-0.3524
G43Z0.25H1
```

The merged g-code file is displayed

# Related Topics

User Interface

**Project Tab** 

Load

<u>Info</u>

Transform

**Z** Instance

XY Instance

Save

**Output** 


#### 5.4.2 Transform

You can use this command to perform transformations on a selected g-code file.
The transformations include Move, Rotate, Mirror and Scale. Each method is documented in the topics below. Each tab of the Transform dialog below includes an example.

### To Access this Command:



### Transform menu item



G-Code Browser: Transform menu item


## Procedure

- 1. Select the g-code file from the Project tab that you wish to transform.
- 2. Select Transform from the Project tab menu. The Transform dialog will display.
- 3. Select the type of transformation to make by selecting the corresponding tap at the top of the dialog (Move, Rotate, Mirror or Scale).
- 4. Complete the necessary data fields and then pick OK from the dialog to perform the transformation.

5. The transformation is displayed in the graphics screen and the g-code file is flagged for Output.

# Transform dialog, Move tab

The Move tab of the Transform Toolpath dialog allows you to translate the toolpath by specifying From and To points for the move. You can either specify these points by coordinate entry in the corresponding edit fields or could graphically pick the points by selecting the Pick buttons. Once the points are specified, selecting the apply button will perform the move operation.



Dialog Box: Transform Toolpath, Move tab

#### **Move From**

Enter the X,Y,Z coordinate values for the Move From point or select the Pick From Part button to select a point from the model.


#### **Move To**

Enter the X,Y,Z coordinate values for the Move To point or select the Pick To Part button to select a point from the model.

#### **Number of Copies**


You can also Copy the toolpath by entering the number of copies.

**Example**: The original g-code file is moved along the Y axis making 3 copies.



Transform Dialog, Rotate tab

Selecting the Rotate tab allows you to rotate the toolpath.



Dialog Box: Transform Toolpath, Rotate tab

#### Axis / About(P) / Angle

Rotation can be performed around any of the three principal axes. The angle of rotation as well as the point and Axis of rotation can be specified.


The point of rotation could be one of the Origin, Center of the part, Minimum point of the part and the Maximum point of the part.

The Axis of rotation could be the X, Y or the Z Axis. You can specify any arbitrary rotation Angle.

#### **Number of Copies**


You can also Copy the toolpath by entering the number of copies.

**Example**: The original g-code file is rotated about the Z axis by 45 degrees.



# Transform Dialog, Mirror tab

Selecting the Mirror tab allows you to Mirror the selected toolpath.



Dialog Box: Transform Toolpath, Mirror tab

#### **Mirror Plane**

Select the Mirror Plane from the list (XY Plane, XZ Plane or YZ Plane).

#### Point (P)


Select a Mirror Point (P) from the list (Origin, Center of the part, Minimum point of the part) or enter the X,Y,Z coordinate values of the desired point.

You can also select the Pick Plane Point button to select a point from the model.

#### **Create Copy**


Check this box to create a Copy of the mirrored toolpath.

**Example**: The original g-code file is mirrored about the YZ plane keeping the original.



# Transform Dialog, Scale tab

Selecting the Scale tab allows you to scale the selected toolpath. All scaling is performed about the zero of the coordinate axes. You can optionally scale from a mm to an inch or vice-versa or by specifying a scale factor. You can also scale the selections uniformly or perform non-uniform scaling in each of the three principal axes.



Dialog Box: Transform Toolpath, Scale tab

#### **Scale Units**

Select the Scale Units from the list (To Millimeters or To Inches).


#### **Uniform Scaling**

Select this option and then enter the uniform X,Y and Z scale factors.

#### **Non-Uniform Scaling**

Select this option and then enter the actual non-uniform X,Y and Z length values.

**Example**: The original g-code file is scaled by 1.5 times the size of the original.



## Related Topics

<u>User Interface</u>

**Project Tab** 

Load

Info

**Merge Files** 

**Z** Instance

XY Instance

Save

**Output** 


#### 5.4.3 Z Instance

Z Instance You can create multiple Z level instances of the toolpath via this dialog. This can be useful in situations where you are manufacturing multiple instances of the same part or want to create multiple z levels of the original path.

#### To Access this Command:



#### Z Instance menu item



G-Code Browser: Z Instance menu item


# Procedure

- 1. Select the g-code file from the Project tab that you wish to Z Instance.
- 2. Select Z Instance from the Project tab menu. The Z Instance dialog will display.

- 3. Enter the Z Spacing and # in Z values and then pick OK from the dialog.
- 4. The g-code is instanced in the Z axis.

# Instance Toolpath in Z dialog

The g-code will be copied multiple times in the Z axis. Negative values can be specified in the Z spacing. In this case the instances will proceed below the current location of the toolpath.



Dialog Box: Instance Toolpath in Z Dialog


#### **Spacing**

Specify the Spacing between the toolpaths in the Z direction.

#### #in Z

Specify the total number of instances of the toolpath to create.

**Example**: The original g-code file is moved along the Y axis making 3 copies.



Related Topics

**User Interface** 

**Project Tab** 

Load

Info

Merge Files

**Transform** 

XY Instance

Save

**Output** 

#### 5.4.4 XY Instance

XY Instance


You can create multiple instances of the g-code using this command. This can be useful in situations where you are manufacturing multiple instances of the same

part.

## To Access this Command:



# XY Instance menu item




G-Code Browser: XY Instance menu item

Procedure

- 1. Select the g-code file from the Project tab that you wish to Z Instance.
- 2. Select Z Instance from the Project tab menu. The Z Instance dialog will display.
- 3. Enter the Z Spacing and # in Z values and then pick OK from the dialog.
- 4. The g-code is instanced in the Z axis.

# Instance Toolpath in a Rectangular Array dialog

You can specify multiple instances in the X and Y directions in two different ways.



Dialog Box: XY Instance Dialog

## Method = Spaced

Using the Spaced method, you specify the independent X Spacing and Y Spacing values between the toolpaths.

The spacing is then used and applied to the bounding box of the part geometry as shown in the picture on the dialog.

Enter the number of copies of the instanced toolpath using the # in X and # in Y values.

Method = Fitted

Using the Fitted method, you specify a rectangle in which the toolpaths will be fitted by using the X Length and Y Length values.


The bounding box of the part geometry is considered when computing the number of toolpaths that can be fitted in the specified space.

# Order

The order of the instancing can also be specified by selecting either X First or Y First

# **Example**

**Example**: The original g-code file is arrayed on the XY plane spaced 2.5 apart in X and 5.0 apart in Y with a total of 3 copies in each direction.



# Related Topics

User Interface

**Project Tab** 

Load

Info

**Merge Files** 

Transform

**Z** Instance

Save


**Output** 

#### 5.4.5 Save




Use this command to Save a selected G-Code file to the Save Directory specified in the Preferences dialog under <u>Text Editor Preferences</u>.

To Access this Command:



### Save menu item



G-Code Browser: Save menu item

## Procedure

- 1. Select one or more g-code files from the Project tab.
- 2. Select Save from the Project tab menu. The g-code files are saved to the Save Directory specified in the <u>Text Editor Preferences</u> dialog.

This is the save directly by default:

C:\ProgramData\MecSoft Corporation\RhinoCAM 2023 for Rhino 7.0\Edited files\

# Related Topics

<u>User Interface</u>

**Project Tab** 

Load

Info

**Merge Files** 

**Transform** 

**Z** Instance

XY Instance

#### **Output**


### **5.4.6** Output

Use this command to Output a selected G-Code file to the program specified in the Preferences dialog under <u>Text Editor Preferences</u>. For example it could be output to another text editor or a DNC program to go directly to your CNC machine.

# To Access this Command:



### Output menu item



G-Code Browser: Output menu item

## Procedure

- 1. Select a g-code files from the Project tab.
- 2. Select Output from the Project tab menu. The g-code file is sent to the Program to Output specified in the <u>Text Editor Preferences</u> dialog.

By default the Program to Output is set to notepad.

Related Topics
User Interface

Project Tab

Load

<u>Info</u>

Merge Files

**Transform** 

**Z** Instance

XY Instance

Save

# 5.5 Right-Click Menu


### 5.5.1 Edit-G-Code-File



To Access this Command:



Right-Click Menu



G-Code Browser, Project Tab

#### Procedure

- Select a G-Code file that is currently loaded into the Project tab of the G-Code Browser.
- 2. Right-click and select Edit from the menu.
- 3. The G-Code file is loaded into the Edit tab of the G-Code Browser.

# Related Topics

Edit-G-Code-File

Simulate G-Code File

Info on G-Code File

Delete G-Code File

#### 5.5.2 Simulate G-Code File




Use this command to Simulate a G-Code file that is currently loaded into the Project tab of the G-Code Browser.

To Access this Command:



### Right-Click Menu



G-Code Browser, Project Tab

### Procedure

- Select a G-Code file that is currently loaded into the Project tab of the G-Code Browser.
- 2. Right-click and select Simulate from the menu.
- 3. The G-Code file is loaded into the Simulate tab of the G-Code Browser.

# Related Topics


Edit-G-Code-File

Simulate G-Code File

Info on G-Code File

Delete G-Code File

#### 5.5.3 Info on G-Code File




Use this command to display Information about a G-Code file that is currently loaded into the Project tab of the G-Code Browser.

## To Access this Command:



# Right-Click Menu



G-Code Browser, Project i

## Procedure

- 1. Select a G-Code file that is currently loaded into the Project tab of the G-Code Browser.
- 2. Right-click and select Info from the menu.

# Related Topics

Edit-G-Code-File
Simulate G-Code File

Info on G-Code File
Delete G-Code File

#### 5.5.4 Delete G-Code File




Use this command to Delete a G-Code file that is currently loaded into the Project tab of the G-Code Browser.

### To Access this Command:



# Right-Click Menu



G-Code Browser, Project Tab

## Procedure

- 1. Select a G-Code file that is currently loaded into the Project tab of the G-Code Browser.
- 2. Right-click and select Delete from the menu.
- 3. The G-Code file is removed from the Project tab.

Related Topics

Edit-G-Code-File

Simulate G-Code File

Info on G-Code File

Delete G-Code File


### **Edit Tab**

When you double-left-click on a G-Code file from the Project tree, that file is loaded into the G-Code Editor. The Edit tab contains commands to Modify and Navigate the g-code file. The Edit tab and commands are listed below.

#### To Access this Command:



### Edit tab



# Ribbon Bar Options

Edit Contains file Edit related commands.




Print the G-Code file currently loaded in the editor.

Undo

Print

**Edit Tab** 



lnfo Display information about the current g-code file.

## Edit Tab, Right-Click Menu



Go to the Top (Start) of the G-Code file.

Go to the next Tool Change code.

Spindle Go to the next Spindle code.

Feedrate Go to the next Feedrate code.

Cut the selected text to the clipboard.

Copy the selected text to the clipboard.


Paste the selected text to the current cursor location.

Find text within the G-Code file.

✓ Replace... Find & Replace text within the G-Code file.


Undo Undo the last command.


## Edit Tab, Display Toolbar



B

Stock Model Visibility: Turn on/off stock model





- Follow Toolpath Display: The toolpath is displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath after the tool passes.
- Trace Toolpath Display: The toolpath is not displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath before the tool passes.
- Segment Toolpath Display: The toolpath is only displayed for the segment that the tool is currently on.

### Related Topics

**Project Tab** 

**Project Tree** 

Simulate Tab

Online Help

#### 6.1 Add Line Numbers


Use this command to Add Line Numbers to the g-code file. Comments are not assigned line numbers. These line numbers are included when you save or output the g-code file. The line numbers you see to the far left are for reference within the G-Code Editor only and are not included in the g-code file.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

Add Line # menu item



G-Code Browser: Edit G-Code tab, Add Line # menu item

#### Procedure

1. Select Add Line #s from the Edit tab. This will insert consecutive line numbers at the beginning of every line that contains g-code. Note that comments are not numbered.

### Related Topics

<u>User Interface</u>

**G-Code Browser** 

**G-Code Edit Tab** 

**Delete Line Numbers** 

**Insert Spaces** 

**Delete Spaces** 

Make Upper Case

Make Lower Case

**Show G-Code Info** 

### 6.2 Insert Spaces


Insert Spaces Use this command to Insert Spaces between g-codes. These are also referred to as "delimiters". One space is inserted between each g-code. An example of inserted spaces is shown in the example below.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

### Insert Spaces menu item



G-Code Browser: Edit G-Code tab, Insert Spaces menu item

# Procedure

1. Select Insert Spaces from the Edit tab. This will insert one a space character between all g-codes in the g-code file.

# Related Topics

**User Interface** 

**G-Code Browser** 

**G-Code Edit Tab** 

Add Line Numbers

**Delete Line Numbers** 

**Delete Spaces** 

Make Upper Case

Make Lower Case

**Show G-Code Info** 

#### **Make Upper Case** 6.3


**Upper Case** Use this command to convert all alphabetic letters to Upper Case in the g-code file. An example of this is shown in the menu example below.

# To Access this Command:



Note: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

## **Upper Case menu item**



G-Code Browser: Edit G-Code tab, Upper Case menu item

# Procedure

1. Select Upper Case from the Edit tab. This will convert all alphabetic letters to Upper Case characters in the g-code file.

Related Topics

<u>User Interface</u>

**G-Code Browser** 

G-Code Edit Tab

**Add Line Numbers** 

**Delete Line Numbers** 

**Insert Spaces** 

**Delete Spaces** 

Make Lower Case

Show G-Code Info

### 6.4 Delete Line Numbers

Del Line #s


Use this command to Delete Line Numbers in the g-code file. Comments are not assigned line numbers. Line numbers, if displayed, are included when you save or output the g-code file. The line numbers you see to the far left are for reference within the G-Code Editor only and are not included in the g-code file.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

Delete Line # menu item



G-Code Browser: Edit G-Code tab, Delete Line # menu item

#### Procedure

 Select Del Line #s from the Edit tab. This will remove all consecutive line numbers from the beginning of every line that contains g-code. Note that comments are not numbered.

### Related Topics

**User Interface** 

**G-Code Browser** 

**G-Code Edit Tab** 

**Add Line Numbers** 

**Insert Spaces** 

**Delete Spaces** 

Make Upper Case

Make Lower Case

**Show G-Code Info** 

### 6.5 Delete Spaces


Use this command to Delete Spaces between g-codes. These are also referred to as "delimiters". One space is deleted between each g-code. An example of deleted spaces is shown in the example below.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

## Delete Spaces menu item



G-Code Browser: Edit G-Code tab, Delete Spaces menu item

# Procedure

1. Select Del Spaces from the Edit tab. This will remove all space characters between all g-codes in the g-code file.

# Related Topics

**User Interface** 

**G-Code Browser** 

G-Code Edit Tab

**Add Line Numbers** 

**Delete Line Numbers** 

**Insert Spaces** 

Make Upper Case

Make Lower Case

**Show G-Code Info** 

#### **Make Lower Case** 6.6


Lower Case Use this command to convert all alphabetic letters to Lower Case in the g-code file. An example of this is shown in the menu example below.

## To Access this Command:



Note: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

#### Lower Case menu item



G-Code Browser: Edit G-Code tab, Lower Case menu item

#### Procedure

1. Select Lower Case from the Edit tab. This will convert all alphabetic letters to Lower Case characters in the g-code file.

## Related Topics

User Interface

**G-Code Browser** 

**G-Code Edit Tab** 

Add Line Numbers

**Delete Line Numbers** 

**Insert Spaces** 

**Delete Spaces** 

Make Upper Case

**Show G-Code Info** 


### 6.7 Cut Text

Use this edit tool to Cut (i.e., delete) the currently highlighted text. The cut text is added to your Windows clipboard and can be Pasted back into any g-code file within the G-Code Editor or other Windows program that can display text.

# To Access this Command:



Cut Text (Right-Click Menu)



G-Code Browser: Edit tab, Cut Text (Right-Click Menu)

### Procedure

- 1. Use the mouse cursor left-click-drag to highlight the text you wish to remove.
- 2. Select Cut from the Edit tab or right-click and select Cut from the menu and the text is removed and added to the Windows clipboard.

## Related Topics

<u>User Interface</u>

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Copy Text** 

**Paste Text** 

**Undo Last Edit** 

**Print G-Code** 

#### Save G-Code


# 6.8 Copy Text

Use this edit tool to Copy the currently highlighted text. The copied text is added to your Windows clipboard and can be Pasted back into any g-code file within the G-Code Editor or other Windows program that can display text.

#### To Access this Command:



### Copy Text (Right-Click Menu)



G-Code Browser: Edit tab, Copy Text (Right-Click Menu)

#### Procedure

- 1. Use the mouse cursor left-click-drag to highlight the text you wish to copy.
- 2. Select Copy from the Edit tab or right-click and select Copy from the menu and the text is copied to the Windows clipboard.

## Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

Paste Text

**Undo Last Edit** 

**Print G-Code** 


Save G-Code

#### 6.9 Paste Text




Use this edit tool to Paste the contents of the Windows clipboard into the g-code file at the location of the cursor.

#### To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file.

Paste Text (Right-Click Menu)



G-Code Browser: Edit tab, Paste Text (Right-Click Menu)

# Procedure

- 1. Use the mouse to locate the cursor in the desired location.
- 2. Select Paste from the Edit tab or right-click and select Paste from the menu and the text is inserted into the G-Code file at the cursor location.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

Copy Text

**Undo Last Edit** 

**Print G-Code** 

#### Save G-Code

#### 6.10 Find Text

**≫** Find...


Use this dialog to Find text within your gcode file. You can use additional options in the Find dialog shown below.

### To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file.

## The Find dialog



Use this dialog to Find text within your gcode file.

#### **Find What**

Enter the text you wish to find and then pick Find Next to locate it.

#### **Find Next**

Go to the next location of the text.

#### **Options**

Match whole word only: Only complete words will be located.

• Match case: Use case sensitivity: Only words that match the upper/lower case will be located.

#### Direction

- Search Up: Search upwards in the g-code file.
- Search Down: Search downwards in the g-code file.

### Procedure

- 1. Select Find from the Edit tab or right-click and select Find from the menu. The Find dialog will display.
- 2. Enter the text to find and then pick Find Next.

## Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

Copy Text

**Paste Text** 

**Find & Replace Text** 

**Undo Last Edit** 

**Print G-Code** 

Save G-Code

# 6.11 Find & Replace Text


Use this dialog to Find & Replace text within your gcode file. You can find and replace all occurrences of text and use additional options in the Find & Replace dialog shown below.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file.

### The Find & Replace dialog



Use this dialog to Find & Replace text within your gcode file.

#### **Find Text**

Enter the text you wish to find and then pick Find Next to locate it.

#### **Find Next**

Go to the next location of the text.

#### **Replace With**

Enter the text you wish to replace with.

#### Replace

Replace the currently highlighted text with the text entered into the Replace With field.

#### **Replace All**

Search the entire g-code file and replace all occurrences of the Find Text with the text entered into the Replace With field.

#### **Options**

- Match whole word only: Only complete words will be located.
- Match case: Use case sensitivity: Only words that match the upper/lower case will be located.

#### Direction

- Search Up: Search upwards in the g-code file.
- Search Down: Search downwards in the g-code file.

- 1. Select Find & Replace from the Edit tab or right-click and select Replace from the menu. The Find & Replace dialog will display.
- 2. Use the Find & Replace dialog shown above to complete the process.

## Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

**Copy Text** 

**Paste Text** 

**Find Text** 

**Undo Last Edit** 

**Print G-Code** 


Save G-Code

#### 6.12 Undo Last Edit




Use this command to Undo the last edit made to the g-code file. You can repeat the selection to Undo all edits made in the current session.

### To Access this Command:



Undo Last Edit (Right-Click Menu)



G-Code Browser: Edit tab, Undo Last Edit (Right-Click Menu)

1. Select Undo from the Edit tab or right-click and select Undo from the menu. The last edit will be undone.

# Related Topics

<u>User Interface</u>

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

**Copy Text** 

**Paste Text** 

**Find Text** 

**Find & Replace Text** 

**Print G-Code** 


Save G-Code

#### 6.13 Print G-Code




Use this command to Print the current g-code file. The default Windows Print dialog will display allowing you to select a printing device and print preferences.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

# Print menu item



G-Code Browser: Edit tab, Print menu item

# Procedure

1. Select Print from the Edit tab. This will display the Windows Print dialog allowing you to select a printer or device to print to.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 


**Copy Text** 

**Paste Text** 

**Undo Last Edit** 

Save G-Code

#### 6.14 Save G-Code



overwritten.


Select this command to Save the g-code file to the default Save Directory defined in the  $\underline{\text{Text Editor Preferences}}$  dialog. You original g-code file IS NOT

## To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

## Save menu item



G-Code Browser: Edit tab, Save menu item

### Procedure

 Select Save from the Edit tab. This will save the g-code file to the default Save Directory defined in the <u>Text Editor Preferences</u> dialog. You original g-code file IS NOT overwritten.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 


**Copy Text** 

**Paste Text** 

**Undo Last Edit** 

Print G-Code

#### **6.15** Save As




To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

Save menu item



G-Code Browser: Edit tab. Save As menu item

1. Select Save from the Edit tab and then Save As. This will save the g-code file to the folder of your choice.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

**Copy Text** 

**Paste Text** 


**Undo Last Edit** 

Print G-Code

#### 6.16 Show G-Code Info


Use this command to display an information window of the current contents of the G-Code Editor.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.


## Info menu item



G-Code Browser: Edit G-Code tab, Info menu item

#### Procedure

- 1. Select Info from the Edit tab.
- 2. This will display the Information dialog containing information related to the current g-code file.



Information dialog

Related Topics

<u>User Interface</u>

**G-Code Browser** 

G-Code Edit Tab

**Add Line Numbers** 

**Delete Line Numbers** 

**Insert Spaces** 

**Delete Spaces** 

Make Upper Case

Make Lower Case

### 6.17 Select Full Line


You can select the full line of code. To do so, first make sure Line Numbers are displayed by selecting Add line #s from the Edit tab menu. Then select the line number displayed in the line number column. This will select the full line of code. Refer to the example below.





**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

Info menu item




G-Code Browser: Edit G-Code tab, Select Whole Line

# 6.18 Right-Click Menu


#### 6.18.1 Go to Bottom

Use this command to move the cursor to the last g-code numbered line in the g-code file.

To Access this Command:



Bottom (Right-Click Menu)



G-Code Browser: Edit tab, Bottom (Right-Click Menu)

1. Select Bottom from the Edit tab. This will move the cursor to the last g-code numbered line in the g-code file.

## Related Topics

Go To Bottom

Go to Top

**Go to Next Tool** 

Go to Next Spindle

Go to Next Feedrate

**Cut Text** 

**Copy Text** 

**Paste Text** 

**Undo Last Edit** 


#### 6.18.2 Go to Top

Top Use this command to move the cursor to the first line in the g-code file.

To Access this Command:



## Top (Right-Click Menu)



G-Code Browser: Edit tab, Top (Right-Click Menu)

## Procedure

1. Select Top from the Edit tab. This will move the cursor to the first line in the g-code file.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 


Go to Bottom

**Go to Next Tool** 

Go to Next Spindle

Go to Next Feedrate

#### 6.18.3 Go to Next Tool




Use this command to move the cursor to the next line in the g-code file that contains a tool number.

### To Access this Command:



# Next Tool (Right-Click Menu)



G-Code Browser: Edit tab, Next Tool (Right-Click Menu)

## Procedure

1. Select Tool from the Edit tab. This will move the cursor to the next line in the g-code file that contains a tool number.

# Related Topics

<u>User Interface</u>

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Go to Bottom

Go to Top

Go to Next Spindle

Go to Next Feedrate

#### 6.18.4 Go to Next Spindle


Spindle

Use this command to move the cursor to the next line in the g-code file that contains a Spindle code.

To Access this Command:



Next Spindle (Right-Click Menu)



G-Code Browser: Edit tab, Next Spindle (Right-Click Menu)

## Procedure

1. Select Spindle from the Edit tab. This will move the cursor to the next line in the g-code file that contains a Spindle code.

# Related Topics

<u>User Interface</u>

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Go to Bottom

Go to Top

**Go to Next Tool** 

**Go to Next Feedrate** 

#### 6.18.5 Go to Next Feedrate


¥ Feedrate

Use this command to move the cursor to the next line in the g-code file that contains a Feedrate code.

To Access this Command:



Next Feedrate (Right-Click Menu)



G-Code Browser: Edit tab, Next Feedrate (Right-Click Menu)

# Procedure

- 1. Select Spindle from the Edit tab. This will move the cursor to the next line in the g-code file that contains a Feedrate code.
- Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Go to Bottom

Go to Top

Go to Next Tool

Go to Next Spindle


#### 6.18.6 Cut Text

Use this edit tool to Cut (i.e., delete) the currently highlighted text. The cut text is added to your Windows clipboard and can be Pasted back into any g-code file within the G-Code Editor or other Windows program that can display text.

# To Access this Command:



Cut Text (Right-Click Menu)



G-Code Browser: Edit tab, Cut Text (Right-Click Menu)

- 1. Use the mouse cursor left-click-drag to highlight the text you wish to remove.
- 2. Select Cut from the Edit tab or right-click and select Cut from the menu and the text is removed and added to the Windows clipboard.

# Related Topics

<u>User Interface</u>

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Copy Text** 

**Paste Text** 

**Undo Last Edit** 

**Print G-Code** 

#### Save G-Code


#### 6.18.7 Copy Text

Use this edit tool to Copy the currently highlighted text. The copied text is added to your Windows clipboard and can be Pasted back into any g-code file within the G-Code Editor or other Windows program that can display text.

#### To Access this Command:



# Copy Text (Right-Click Menu)



G-Code Browser: Edit tab, Copy Text (Right-Click Menu)

- 1. Use the mouse cursor left-click-drag to highlight the text you wish to copy.
- 2. Select Copy from the Edit tab or right-click and select Copy from the menu and the text is copied to the Windows clipboard.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

Paste Text

**Undo Last Edit** 

**Print G-Code** 


Save G-Code

#### 6.18.8 Paste Text




Use this edit tool to Paste the contents of the Windows clipboard into the g-code file at the location of the cursor.

#### To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file.

Paste Text (Right-Click Menu)



G-Code Browser: Edit tab, Paste Text (Right-Click Menu)

- 1. Use the mouse to locate the cursor in the desired location.
- 2. Select Paste from the Edit tab or right-click and select Paste from the menu and the text is inserted into the G-Code file at the cursor location.

# Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

Copy Text

**Undo Last Edit** 

**Print G-Code** 


#### Save G-Code

#### 6.18.9 Undo Last Edit




Use this command to Undo the last edit made to the g-code file. You can repeat the selection to Undo all edits made in the current session.

#### ☐ To Access this Command:



### Undo Last Edit (Right-Click Menu)



G-Code Browser: Edit tab, Undo Last Edit (Right-Click Menu)

1. Select Undo from the Edit tab or right-click and select Undo from the menu. The last edit will be undone.

## Related Topics

**User Interface** 

**Project Tab** 

**Project Tree** 

**Edit Tab** 

**Cut Text** 

**Copy Text** 

**Paste Text** 

**Find Text** 

Find & Replace Text

Print G-Code

Save G-Code


### Simulate Tab

When you double-left-click on a G-Code file from the Project tree, that file is loaded into the G-Code Editor. The Simulate tab contains commands to perform tool motions and cut material simulations of the g-code file. The Simulate tab and commands are listed below. **Note**: You must have <u>Stock</u>, <u>Tool Library</u> and <u>Tool Crib</u> defined before performing a Simulation.

### To Access this Command:



#### Simulate tab



G-Code Browser, Simulate Tab

# Ribbon Bar Options

Simulate Contains file Simulation related commands.

Returns to the Project tab.

Minimizes and maximizes the ribbon bar menu.

- Displays the <u>Preferences</u> dialog.
- Displays the Online Help system.

# Simulate Tab, Options Pane



Simulation speed adjustment (Left: Slow, Right: Fast).

Check to <u>simulate by moves</u>. Uncheck to simulate by distance. See Preferences to set the default mode.

### Simulate Tab, Simulate Pane

Play the simulation.

Step Step through the simulation by distance or by moves.

Step Levels <u>Display</u> simulation in Levels.

To End Go direction to the End result of the simulation.


Pause Pause the simulation.

Stop the simulation.

# Simulate Tab, Display Toolbar



Stock Model Visibility: Turn on/off stock model



- 😿 Toolpath Visibility: Turn on/off toolpath display
- Follow Toolpath Display: The toolpath is displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath after the tool passes.
- Trace Toolpath Display: The toolpath is not displayed as it follows the behind the movement of the tool (i.e., you will only see the toolpath before the tool passes.
- Segment Toolpath Display: The toolpath is only displayed for the segment that the tool is currently on.

## Related Topics

**Project Tab** 

**Project Tree** 

**Edit Tab** 

Online Help

# 7.1 Simulate Options

#### 7.1.1 Simulation Preferences


Preferences Select this button to display the <u>Simulation Preferences</u> dialog. This is the same as selecting > Simulation.

# To Access this Command:




**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate tab, Preferences menu item



G-Code Browser: Simulate, Preferences menu item

1. Select Preferences from the Simulate tab. This will display the <u>Simulate Preferences</u> dialog.



Preferences > Simulation

2. Make desired changes and then pick Apply. Pick OK to close the dialog.

Related Topics

Simulate Tab

**Simulation Speed** 

**Simulation Mode** 

#### 7.1.2 Simulation Speed


You can use this slider to adjust the simulation speed. Left is slower and right is faster. You can set the default speed for simulations from the <a href="Simulation Preferences">Simulation Preferences</a> dialog.

### To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

# G-Code Browser: Simulate, Speed menu item



G-Code Browser: Simulate, Speed menu item

## Procedure

1. Left-click and drag the slider to adjust the <u>Simulation Speed</u>. Left is slower and right is faster.

# Related Topics

Simulate Tab

**Simulation Preferences** 

**Simulation Mode** 

#### 7.1.3 Simulation Mode

You can use this checkbox to Simulate by Moves. If unchecked, the simulation is calculated by distance as defined in the <u>Simulation</u>


Preferences dialog.

To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Mode menu item



G-Code Browser: Simulate, Mode menu item

#### Procedure

- Check the box to Simulate by Moves. Uncheck the box to Simulate by Distance.
   The increment for moves and distance can be controlled from the <u>Simulation</u> <u>Preferences</u> dialog.
- Related Topics

Simulate Tab

**Simulation Preferences** 


**Simulation Speed** 

#### 7.2 Simulation Controls

#### 7.2.1 Play Simulation


Play Select this commend to Play the simulation. If <u>Stock</u> is defined, a cut material simulation is displayed. If no <u>Stock</u> is defined only the tool motions is simulated.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Play menu item



G-Code Browser: Simulate, Play menu item

1. Select Play from the Simulate tab and the simulation will begin from the current tool location.

## Related Topics

Simulate Tab

**Step Thru Simulation** 

**Display Simulation Levels** 

Simulate to End

**Pause Simulation** 

**Stop Simulation** 

#### 7.2.2 Step Thru Simulation


Step Select this command to Step through the simulation. Each step is determined by the Simulation Mode. You can control this from the Simulation Preferences dialog.

#### To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Step menu item



G-Code Browser: Simulate, Step menu item

1. Select Step from the Simulate tab and the simulation will advance by one increment. The increment is determined by the <u>Simulation Mode</u>. You can control this from the <u>Simulation Preferences</u> dialog.

### Related Topics

Simulate Tab

**Play Simulation** 

**Display Simulation Levels** 

Simulate to End


**Pause Simulation** 

**Stop Simulation** 

## 7.2.3 Display Simulation Levels


Step Levels If your toolpath has multiple Z levels, you can select this command to move the tool to the end of each level. If Stock is defined, the cut material simulation at each Z level is displayed.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Step Levels menu item



G-Code Browser: Simulate, Step Levels menu item

1. Select Step Levels from the Simulate tab and the simulation will advance to the end of the current Z level.

# Related Topics

Simulate Tab

**Play Simulation** 

**Step Thru Simulation** 

Simulate to End

**Pause Simulation** 

**Stop Simulation** 

#### 7.2.4 Simulate to End


To End You can select this command to move the End of the simulation. If Stock is defined, the final cut material simulation is displayed.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, To End menu item



G-Code Browser: Simulate, To End menu item

1. Select To End from the Simulate tab to move the End of the simulation.

### Related Topics

Simulate Tab

**Play Simulation** 

**Step Thru Simulation** 

**Display Simulation Levels** 

**Pause Simulation** 

**Stop Simulation** 

#### 7.2.5 Pause Simulation


Pause You can select this command to Pause the simulation at the current tool location. If Stock is defined, the cut material simulation is also paused.

# To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Pause menu item



G-Code Browser: Simulate, Pause menu item

1. Select Pause from the Simulate tab to Pause the simulation at the current tool location.

# Related Topics

Simulate Tab

**Play Simulation** 

**Step Thru Simulation** 

**Display Simulation Levels** 

Simulate to End

**Stop Simulation** 

#### 7.2.6 Stop Simulation


You can select this command to Stop the simulation at the current tool location. If <u>Stock</u> is defined, the cut material simulation is also stopped.

## To Access this Command:



**Note**: To access this tab activate (i.e., double-left-click) on a loaded g-code file from the Project tab.

G-Code Browser: Simulate, Stop menu item



G-Code Browser: Simulate, Stop menu item

# Related Topics

Simulate Tab

**Play Simulation** 

**Step Thru Simulation** 

**Display Simulation Levels** 

Simulate to End

**Pause Simulation** 

### **Functions from the MILL Module**


You can access the G-Code Editor module from within the MILL module by clicking on the G-Code icon located in each machining operation (Mop) folder as shown below if the icon is not flagged. However, ONLY the Edit tab is available and you cannot simulate G-Code.

#### How G-Code is Stored


Your G-Code data is stored with your CAM part files. When you generate a toolpath operation in the MILL module the G-Code related to that operation is stored with the CAM part file. This means that you will always have access to the latest G-Code generated for any operation.

# To Access G-Code from the MILL Module

To access the G-Code Editor from an operation that you have generated within the MILL module simply click on the G-Code icon within the mop folder as shown below:



The Machining Browser will be replaced with the Edit tab of the G-Code Editor as shown below. To return to the MILL module pick the left arrow icon at the top of the G-Code Editor browser as shown below.



G-Code Browser: Tool Crib menu item

# **Find More Resources**

Download this PDF Guide for a list of the available RhinoCAM Resources.



# Index

# - A -

Add Line Numbers 93

# - C -

#### Colors

Cut Stock 19 Cutting Tool 20 Stock Text Editor 16 **Tool Motion Display** 17 Copy Text 103, 125 Cut Text 101, 123 **Cutting Tools** Crib 62 Library 60 Preferences 20

# - D -

#### Delete

a G-Code File from the Project 88

Delete Line Numbers 97

Delete Spaces 99

Display Toolbar

Toggle Follow Toolpath Display 31, 90

Toggle Part Visibility 31, 90

Toggle Segment Toolpath Display 31, 90

Toggle Stock Visibility 31, 90

Toggle Toolpath Visibility 31, 90

Toggle Trace Toolpath Display 31, 90

# - E -

#### Edit

G-Code File 84
Edit > Select Full Line 116
Edit Tab 31, 90

# - F -

Find Text 106

# - G -

#### G-Code

Add Line Numbers Copy Text 103, 125 Cut Text 101, 123 Delete Line Numbers 97 **Delete Spaces** Find Text 106 From the MILL Module 142 Go to Bottom 117 Go to Next Feedrate 122 Go to Next Spindle 121 Go to Next Tool 119 Go to Top Information 65 Insert Spaces Load 64 Make Lower Case 100 96 Make Upper Case Merge Files 67 Output 104, 126 Paste Text Print G-Code 111 Replace Text 107 Save 81 Save As 113 Save G-Code 112 Show Info 114 Transform 71 Undo Last Edit 109, 128 XY Instance 79 Z Instance 77 G-Code Editor About 5 Features of Overview 5 Understanding Workflow

- H - Help 37	Preferences 12 Cutting Tools 20 Simulation 21, 132 Stock 19 Text Editor 16 Toolpath 17 User Interface 13
Information G-Code 65	Print G-Code 111 Project
on a G-Code File 87 Insert Spaces 95	Tab 26, 39 Tree 28
- L -	- R -
Load G-Code 64	Replace Text 107 Rotate G-Code 71
- M -	- S -
Machine Tool Setup 41 Make Lower Case 100 Make Upper Case 96 MCS Setup 41 Merge Files 67 MILL Module 142	Save As 113 Save G-Code 81, 112 Scale G-Code 71 Select Full Line 116
Mirror G-Code 71 Move G-Code 71	Show G-Code Info 114 Simulate G-Code File 85 Tab 35, 130
- N -	Simulation Display Levels 137
Navigate Go to Bottom 117 Go to Next Feedrate 122	Mode 134 Pause 139 Play 135
Go to Next Spindle 121	Preferences 21, 132
Go to Next Tool 119 Go to Top 118	Speed 134 Step Thru 136 Stop 140
- O -	To End 138 Stock
Output G-Code 83	Box 46 Cylinder 51 Delete 57
- P -	from Selection 58 Menu 45
Part Toggle Visibility 31 90	Part Box 49
Toggle Visibility 31, 90 Paste Text 104, 126	Part Cylinder 54 Preferences 19
•	1 10101011000 10

Stock Toggle Visibility 31, 90 Transparency - T -Text Editor Preferences 16 Toggle Follow Toolpath Display 31, 90 Toggle Part Visibility 31, 90 Toggle Segment Toolpath Display 31, 90 Toggle Stock Visibility 31, 90 Toggle Toolpath Visibility Toggle Trace Toolpath Display 31, 90 Tool Crib 62 Tool Library 60 Toolpath Display width 17 Follow Display 31, 90 Preferences Segment Display 31, 90 Toggle Visibility 31, 90 Trace Display 31, 90 Tools (See Cutting Tools) Transform G-Code Mirror 71 Move 71 Rotate 71 Scale 71 Undo Last Edit 109, 128 User Interface 12 Display Toolbar 31, 90 Edit Tab 31, 90 23 G-Code Browser Preferences 13 Project Tab 26, 39

- Z -

Z Instance G-Code 77

Where to go for more help 144

# - X -

XY Instance G-Code 79